


Ignition Controlled Fuse Box on Fuse Panel

**Fuse B** Stop Lamps, Direction Indicator  
**Fuse D** Reversing Lamps, Battery Condition Indicator  
**Fuse 17/18** Hazard

Cable Colour Code	
B	Black
U	Blue
N	Brown
G	Green
K	Pink
P	Purple
O	Orange
R	Red
S	Slate (Grey)
W	White
Y	Yellow
Modifiers	
D	Dark
L	Light
M	Medium



C.R.Foster  
11/09/99

### Wiring Diagram for BRISTOL 603 Flasher, Hazard, Stop & Reversing Lamps, Battery Condition Indicator

Data from Bristol Cars  
**B 680044**